



Solenoids, Relays & Breakers



Sole-01
85-amp solenoid



Rela-05
50/30-Amp.



Breakers With-
out Bracket



Breakers with
bracket

Solenoids	
SOLE-01	75-amp solenoid
SOLE-200A	200- amp solenoid
RELA-01	Transfer switch (110 volt relay)
DIOD-01	C-amp diode
DIOD-02	6-amp diode
DIOD-04	50-amp diode
Relays	
RELA-05A	50/30-amp, plastic tab
140-1030	50/30-amp., metal tab
140-0379	75-amp., 2 hole mtg.
Auto Reset Breakers	
BRKR-19K	10-amp w/o bracket
BRKR-18K	15-amp, w/o bracket
BRKR-02K	20-amp, w/o bracket
BRKR-05K	30-amp, w/o bracket
BRKR-08K	40 amp, w/o bracket
BRKR-10K	10-amp, with bracket
BRKR-17K	15-amp with bracket
BRKR-04K	20-amp with bracket
BRKR-07K	30-amp with bracket
BRKR-09K	40-amp with bracket
BRKR-20K	50-amp with bracket